

Here are some special tricks to applying 303 High Tech Fabric Guard correctly

- Make sure the surface you are treating is clean
- Make sure the surface you are treating is dry

Do not overspray! Saturation is not necessary

The surface needs to be slightly damp but not soaked. The polymer 303 uses in it's Fabric Guard helps the product go down deep into the fabric. There is no need to treat both sides of the surface. The top side is preferred.

Maintenance is essential

You can lightly mist the surface every 6 months to check the water repellency. Friction will wear away product more quickly leaving the fabric unprotected. If this is the case ... such areas can be spot treated to renew repellency.